

How to Adjust your Startrek Treeless Saddle



The adjustable pommel



Undo the leather cover



to reveal the socket



The adjusting Wrench



Insert the adjusting Wrench




Turn anti-clockwise to loosen nut in socket

Manually widen or narrow the pommel with your hands...



Turn clockwise to tighten nut in socket



Velcro closed the leather cover



Move the Velcro foam panels to suit.